



Press your stamp down about 5mm and push in the red locking button (located on side).



Push the pad out.



Remove the cover from your new pad.

Push the new pad in, (with the inked side facing downwards)



Push the stamp down a little to release the locking mechanism.